

**Lista kompatybilnych modemów
Router CDW463AM**

Producent	Model	Interfejs
AIKO	81D	USB
AIKO	82D	USB
AIKO	83D	USB
Alcatel	X060	USB
Alcatel	X200	USB
Amoi	V870	USB
AnyData	APE-540H	ExpressCard
APBW	WH200 II	USB
ASUS	T500	ExpressCard
ASUS	T600	USB
AT&T	Mecury	USB
BandLuxe	C180	USB
BandLuxe	C321	USB
BandRich	BandLuxe C-100	ExpressCard
BandRich	BandLuxe C-120	USB
BandRich	BandLuxe C-170	USB
BandRich	BandLuxe C-270	USB
BES	WM61	USB
C-Motech	CGU-628A	USB
C-Motech	CGU-629	USB
C-Motech	CGU-629C	USB
C-Motech	CHU-629S	USB
C-Motech	XS Stick W12	USB
C-Motech	XS Stick W14	USB
C-Motech	CCU-550	USB
C-Motech	D-50	USB
C-Motech	U680	USB
C-Motech	CBU-410S	USB
Cricket	A600	USB
Datang	AirCard901	USB
Datang	DTM5731E	USB
D-Link	DWM-151	USB
D-Link	DWM-152	USB
D-Link	DWM-156	USB
D-Link	DWM-162-U5	USB
D-Link	DWM-168	USB
EpiValley	Model 220	USB
EpiValley	SEC-7089	USB
ESTON	EST-618U	USB
ESTON	EST-638U	USB
E-TEL	ET230U	USB
Fly Card	FLY-HU1	USB
Franklin	CGU-628A	USB
Franklin	CGU-629	USB
Franklin	CDU-550	USB
Franklin	CDU680	USB
Giant	D301	USB

Gigabyte	GSMART MD800	ExpressCard
Haier	EM100	USB
Haier	VMW310	USB
Haier	WM100	USB
Haier	WM200	USB
Haier	WM500	USB
Haier	CE100	USB
Haier	CE310	USB
Haier	CM200	USB
Haier	VME110	USB
Haier	HT-DM300	USB
Hisense	E6801	USB
Hojoy	733	USB
Hojoy	TD368	USB
Honest	UC128	USB
Huawei	D01HW	USB
Huawei	D02HW	USB
Huawei	D12HW	USB
Huawei	D21HW	USB
Huawei	D22HW	USB
Huawei	D23HW	USB
Huawei	D31HW	USB
Huawei	E1152	USB
Huawei	E122	USB
Huawei	E1550	USB
Huawei	E1552	USB
Huawei	E1553	USB
Huawei	E156G	USB
Huawei	E160	USB
Huawei	E160E	USB
Huawei	E160G	USB
Huawei	E161	USB
Huawei	E169	USB
Huawei	E169U	USB
Huawei	E170	USB
Huawei	E172	USB
Huawei	E1750	USB
Huawei	E1756	USB
Huawei	E1762	USB
Huawei	E176G	USB
Huawei	E180	USB
Huawei	E1820	USB
Huawei	E182E	USB
Huawei	E220	USB
Huawei	E226	USB
Huawei	E270	USB
Huawei	E510	USB
Huawei	K3520	USB
Huawei	K3565	USB
Huawei	K3715	USB

Huawei	K3765	USB
Huawei	E1260	USB
Huawei	EC122	USB
Huawei	EC1260	USB
Huawei	EC1261	USB
Huawei	EC168	USB
Huawei	EC169	USB
Huawei	EC189	USB
Huawei	EC226	USB
Huawei	EC228	USB
Huawei	ET128	USB
KPT	WM66	USB
Kyocera	UTU1900D	USB
Lenovo	SPRD-8800	USB
LightSpeed	EDGE-180M	USB
LightSpeed	HSDPA-180C	USB
Long Cheer	71 11	USB
Long Cheer	C01LC	USB
Long Cheer	C02LC	USB
Long Cheer	D11LC	USB
Long Cheer	D12LC	USB
Long Cheer	D21LC	USB
Matrix	MTX-H25	USB
Maxon	USB3-8521	USB
MLW Telecom	SU-8100U	USB
MLW Telecom	SU-8200	USB
MLW Telecom	SU-8500U	USB
MLW Telecom	SU-8600U	USB
MLW Telecom	SU-9000U	USB
MLW Telecom	SU-6200	USB
Motorola	H24	USB
NOKIA	CS-10	USB
NOKIA	CS-15	USB
Novatel	EU850D	USB
Novatel	MC930D	USB
Novatel	MC935D	USB
Novatel	MC950D	USB
Novatel	MC990D	USB
Novatel	MC996D	USB
Novatel	MiFi2352	USB
Novatel	NRM-XU870	ExpressCard
Novatel	X950D	ExpressCard
Novatel	ES720	USB
Novatel	MC727	USB
Novatel	MC760	USB
Novatel	U720	USB
Novatel	U727	USB
Novatel	U760	USB
NTT Docomo	L-05A	USB
Onda	DT515HS	USB

Onda	MSA405HS	USB
Onda	MSA501HS	USB
Option	GE0201	ExpressCard
Option	GI0322	USB
Option	Globe Trotter	ExpressCard
Option	GT EXPRESS 7.2	ExpressCard
Option	GTM382	USB
Option	HSUPA-380P	USB
Option	ICON 225	USB
Option	ICON 401	USB
Option	ICON 431	USB
Option	iCon 515	USB
Option	iCon031	USB
Option	iCon451	USB
Option	iCon452	USB
Option	iCon505	USB
Option	iCon XY	USB
Pantech	UM150	USB
Pantech	UM175	USB
Pantech	UM185AL	USB
Pin Su	EU930	USB
Prolink	PHS100	USB
Prolink	PHS300	USB
Promate	E-GO3	USB
Qsida	Flying Beet(H21)	USB
Quanta Computer	GKD	USB
Quanta Computer	GQR	USB
Quanta Computer	MU-Q101	USB
Quanta Computer	Q110	USB
QuickTel	HM405	USB
Samsung	Z800	USB
Samsung	SGH-H128	USB
SHber	H951	USB
SHber	H955	USB
SHber	H956	USB
SHber	E750	USB
SHber	E751	USB
SHber	E751+	USB
SHber	E752	USB
SHber	E753+	USB
Sierra Wireless	875U	USB
Sierra Wireless	AC501	ExpressCard
Sierra Wireless	AC503	ExpressCard
Sierra Wireless	AC880E	ExpressCard
Sierra Wireless	AC881U	USB
Sierra Wireless	AC885	USB
Sierra Wireless	Compass 885U	USB
Sierra Wireless	Compass 888 889	USB
Sierra Wireless	USB306/USB307	USB
Sierra Wireless	USB308	USB

Sierra Wireless	USB309	USB
Sierra Wireless	AC310U	USB
Sierra Wireless	595U	USB
Sierra Wireless	598U	USB
Sierra Wireless	AC595DORA	ExpressCard
Sierra Wireless	AC597U	USB
SIMCOM	U6-T	USB
SIMCOM	U9R-T	USB
Solomon	D12LC	USB
Solomon	S3GM-646	USB
Solomon	S3GM-660	USB
Solomon	S3GM-690	USB
Solomon	SEGM-520C	USB
Sony Ericsson	MD300	USB
Sony Ericsson	MD400	USB
Sprint	U598	USB
Sprint	U760	USB
Tactio	MD72U	USB
TeleWell	TW-3G	ExpressCard
Telit	UC864	USB
UTStarcom	C6805	USB
UTStarcom	Q6085(CU189)	USB
UTStarcom	UM100	USB
UTStarcom	UM150	USB
UTStarcom	UM175	USB
Verizon	ES720	USB
Verizon	PC770	ExpressCard
Verizon	UM175	USB
Vodafone	EasyBox	USB
Vodafone	K4505	USB
Vtion	E1916	USB
Vtion	V1810	USB
Vtion	U1916	USB
Webee	Modem Configuration	USB
Zoom	4593	USB
Zoom	72TRI	USB
ZTE	K3520	USB
ZTE	K-3565-Z	USB
ZTE	MF 110	USB
ZTE	MF100	USB
ZTE	MF620	USB
ZTE	MF622	USB
ZTE	MF626	USB
ZTE	MF627	USB
ZTE	MF633	USB
ZTE	MF633BP	USB
ZTE	MF636	USB
ZTE	MF636 BP	USB
ZTE	MF636+	USB
ZTE	MF636-BKIC	USB

ZTE	MF637	USB
ZTE	MF668	USB
ZTE	AC2726	USB
ZTE	AC2736	USB
ZTE	AC560	USB
ZTE	AC580	USB
ZTE	AC8710	USB
ZTE	MV140B	USB
ZTE	MF637U	USB
ZTE	MU-318	USB
ZTE	MU-350	USB
ZTE	MU351	USB